Nodal Ninja 4 - Quick Reference Guide





Lower rotator: tension knob and lock knob.



Using the hex key loosen the inner hex screw enough to release detent ring.



Fits all tripod heads - uses both 3/8" & 1/4" thread mount adapter.



The upper rotator can be installed with an offset of +/- 5, 7.5, or 10 degree from the horizon, making it perfect for single row spherical panoramas with various fisheye lenses.



Only buy from "authorized resellers". If buying new from other than an "authorized reseller", no warranties or product support are included.

For complete manual visit: www.NodalNinja.com For support visit: www.NodalNinja.com/forum For videos visit: youtube.com/nodalninja